

GUIDE

Guide de sélection des volumes - pipettes HandyStep®



► Opérations et gammes de volumes

Position piston	1	2	3	4	5
Nbre d'opérations	49	24	15	11	9
Embout (ml)	Volume de distribution (µl)				
0,1	2	4	6	8	10
0,5	10	20	30	40	50
1,25	25	50	75	100	125
2,5	50	100	150	200	250
5	100	200	300	400	500
12,5	250	500	750	1000	1250
25	500	1000	1500	2000	2500
20	1000	2000	3000	4000	5000